



UK Sampling Gauges Ltd

Building 1, Roman Bank, Bourne, Lincolnshire, PE10 9LQ, UK

Tel: +44 (0)1778 392818 Fax: +44 (0)1778 421169

E-mail: sales@samplinggauges.com

Web site: www.samplinggauges.com



Spot Level Samplers ALS 1001 (Brass), 1002 (St/St)

Applications

ALS samplers are ideally suited to taking true spot samples from any level or depth within a stored liquid, to check for quality, density, or chemical purity, for example.

The ALS sampler has a valve at the top, opened by a snatch on the supporting cable.

In operation, the valve stays closed (and the sampler therefore stays empty) until the sampler reaches the depth at which the sample is required. For this reason, you can be sure that true samples are obtained, uncontaminated and undiluted by liquid from any other level in the tank or reservoir.

The "top hat" feature of the design minimises the effects of "fall-out" from the supporting cable.

Specifications

	ALS 1001	ALS 1002
Overall diameter	64mm	64mm
Overall length	48cm	48cm
Weight (empty)	2.2kg	2.2kg
Capacity	1000ml	1000ml
Material	Brass	316 stainless Steel



ALS 1001

ALS 1002

ALS 1002, open



The full ALS range includes samplers with overall diameters between 38 mm and 152 mm, capacities between 130 ml and 2500 ml, and they are available in brass as well as stainless steel.

Please contact us if you require further information about these or other equipment offered by **UK Sampling Gauges Ltd**, or if you require equipment to be adapted or modified.