



# UK Sampling Gauges Ltd

Building 1, Roman Bank, Bourne, Lincolnshire, PE10 9LQ, UK

Tel: +44 (0)1778 392818 Fax: +44 (0)1778 421169

E-mail: [sales@samplinggauges.com](mailto:sales@samplinggauges.com)

Web site: [www.samplinggauges.com](http://www.samplinggauges.com)



## ATEX & IECEx Approved MK 1A Winder For Use with Our Range of Samplers

### Applications

Ideally suited for use with our range of samplers, our winders are designed and made with the safety and convenience of operators in mind.

The MK 1A Winder was developed for use with our medium-sized samplers. Recent improvements in the design of the winding / locking mechanism have been made. These ensure that the winder makes its contribution to the safety of sampling operations, and to the comfort of the operator. Also cable wiper is fitted.

The winding handle controls the lowering and lifting of the sampler. A simple squeeze of the winding knob releases the lock on the winding reel. Letting go of the knob automatically locks the reel.

The cable is of multi-strand stainless steel to avoid the contamination that can occur with ropes and chains.

The design of the hook minimises the risk of a sampler becoming detached from the winder. The hook and cable,

together with the clamp of the support, ensure electrical continuity and prevent the build-up of static electricity in the sampling system.



ATEX Approved MK 1A Winder  
with cable wiper & optional depth counter

### Specifications

<b>Cable Length and Diameter</b>	30m x 2mm	<b>Weight of Winder</b>	3 kg
<b>Recommended sampler size</b>	Up to 1500ml	<b>Material</b>	Stainless Steel



Please contact us, or scan the QR code, if you require further information about these or other equipment offered by **UK Sampling Gauges Ltd**, or if you require equipment to be adapted or modified.